

128铜版纸/风琴折 展开尺寸: 900x100mm 实际尺寸: 100x100mm

KA66
户外便携无线音箱

用户手册

尊敬的awei用户:

感谢您选用awei产品!您的选择对于我们至关重要,这意味着awei又增加了一名新用户。希望通过我们的产品和服务,为您带来上佳的体验。也希望您在产品使用过程中,通过官方客户热线、微博、微信、等提出好的意见和建议,帮助awei不断完善产品和服务。

如果您在产品使用过程中遇到任何问题,请参阅服务流程,方便、快捷地获取帮助。您的支持是我们成长的动力,您的每一次认可和评价都是对awei莫大的鼓励。谢谢!

awei营销团队

非常感谢您使用awei产品,在使用本产品之前,请仔细阅读本手册。

附件清单

- 1x 无线音箱
- 1x USB-C充电线
- 1x 3.5mm音频线
- 1x 说明书

产品说明图

① 模式键
② 上一首/音量加
③ 内置麦克风
④ 电源开关
⑤ 指示灯

⑥ 上一首/音量减小
⑦ RGB 灯效按钮
⑧ AUX 接口
⑨ USB 接口
⑩ Type-C 充电接口

怎样使用

蓝牙连接

- 首次开机时,音箱将自动进入蓝牙配对模式,蓝灯闪烁。配对时,请打开您的蓝牙设备并搜索“awei KA66”进行配对。
- 连接成功后,蓝灯变为常亮,并会听到连接提示音。
- 断开蓝牙连接,请同时按住“+”和“-”按钮。蓝灯将从常亮变为闪烁,并会听到断开连接提示音。

TWS连接

打开扬声器,指示灯亮起蓝灯。连接蓝牙后,有5种灯光模式可供选择,按下顶部的“*”按钮即可切换。

模式一: RGB灯光与音乐节拍同步。
模式二: RGB灯光与音乐节拍快速同步。
模式三: 七彩灯光与音乐节拍快速同步。
模式四: 七彩灯光与音乐节拍流动。
模式五: 彩虹灯光与音乐节拍流动。

*RGB灯光将按照音量调节的方向流动。

蓝牙电话

- 音箱内置麦克风,可通过蓝牙连接音箱拨打电话。
- 电源键: 来电时,短按接听电话,双击拒接电话。通话中,短按挂断电话。

播放顺序

开机默认为蓝牙模式。当有其他多个音源输入时,播放顺序如下:
第一: 蓝牙模式 第二: USB 模式 第三: AUX 模式
短按“M”键可按以上顺序切换音源输入。

怎样使用

AUX模式

- 将设备的AUX线连接到扬声器的AUX插孔。连接成功后,扬声器将自动切换到AUX模式。
- 在连接的设备上播放音乐。
- 短按电源按钮可静音或取消静音。

RGB灯

打开扬声器,指示灯亮起蓝灯。连接蓝牙后,有5种灯光模式可供选择,按下顶部的“*”按钮即可切换。

模式一: RGB灯光与音乐节拍同步。
模式二: RGB灯光与音乐节拍快速同步。
模式三: 七彩灯光与音乐节拍快速同步。
模式四: 七彩灯光与音乐节拍流动。
模式五: 彩虹灯光与音乐节拍流动。

*RGB灯光将按照音量调节的方向流动。

指示灯

开机: 电源指示灯熄灭。
关机: 电源指示灯蓝灯慢闪。
蓝牙连接: 电源指示灯蓝灯常亮。
AUX IN模式: 电源指示灯蓝灯慢闪。
USB模式: 电源指示灯蓝灯慢闪。
充电: 充电红灯亮,充满红灯灭。

怎样使用

充电

为了更好的产品体验,请在使用前将音箱充满电。包装内带一根Type-C充电线(仅充电,不具备数据传输功能),请使用5V/2A适配器或电脑USB输出进行充电。使用非标配的5V适配器充电可能会损坏产品。如果充电线损坏或设备受损,请勿使用。

电源开/关

- 长按电源按钮2秒打开扬声器,会听到开机提示音。
- 长按电源按钮2秒关闭扬声器,会听到关机提示音。
- “开/关机”提示音固定,音量默认为扬声器最大音量的30%。
- 电池电量低时,会听到低电量提示音,扬声器在三声提示音后自动关机。

省电设置

以下四种状态下,音箱10分钟后自动关机。

- 蓝牙模式下,手机未连接。
- 蓝牙模式下,手机已连接,但10分钟内无任何播放或操作。
- USB模式下,按暂停键,10分钟内无任何播放或操作。
- AUX模式下,按暂停键,10分钟内无任何播放或操作。

其他

- 在任何模式下,长按②前进键6秒以上,可恢复出厂设置并关机,同时清除蓝牙配对记录。
- 默认自动音量为最大音量的50%。播放时间可能因音量和音乐风格而异。

产品规格

1. 蓝牙版本:	V5.3
2. 防水等级:	IPX7
3. 电池容量:	3000 mAh/7.4v
4. 播放时间:	7小时(50%音量)
5. 充电时间:	3小时
6. 响应频率:	80-16KHZ
7. 蓝牙有效距离:	>10M
8. 充电输入标准:	DC 5V (Type-C)
9. 输出功率:	60W
10. 支持模式:	BT/USB/AUX/TWS/免提通话/RGB灯
11. 产品尺寸:	96.2*96.2*237.7mm

安全与保养

请阅读以下提示,以帮助延长产品使用寿命,并清楚保修条款。

- 保持产品干燥,勿将产品放在潮湿的地方,以免影响产品内部电路。
- 不要将产品放置在太阳直射或者高温的地方,避免高温电子产品的使用寿命缩短,使某些塑料部件变形。
- 不要将产品放在尖锐的地方,以免损坏内部电路。
- 不要试图拆卸产品,尤其非专业人士,可能会损坏产品。
- 不要跌落、强烈震动、用硬体撞击产品,以免损坏内部电路。
- 不要使用腐蚀性化学物质,清洁时请用清水。
- 不要将液体在产品表面洒上,以免损坏外壳和影响寿命。
- 不要对机器连续充电超过10小时,以免影响使用寿命。

如产品不能正常工作,请联系至awei的授权维修机构,工作人员会热心帮您解决问题。
声明: 为提高产品性能我们会对产品升级,本说明内容可能会有所变更,恕不另行通知,敬请谅解,感谢您的选购!

产品售后服务指南

一、七天无理由
A. 包退期限: 用户在awei直属专卖店或经awei授权的经销商所购买的产品,自购买之日起7天内,产品未受到任何人为或外力的损害而发生的产品质量问题,厂家包退。
B. 退货流程: 用户将产品、包装和原发票完整地拿到(或自购邮到)购买地点给商家检测——商家按原保规定期退换货,鉴定该产品是否有产品质量问题——商家退还用户购买产品所付的货款。

二、十五天包换
A. 包换期限: 用户在awei直属专卖店或经awei授权的经销商所购买的产品,自购买之日起15天内,产品未受到任何人为或外力的损害而发生的产品质量问题,厂家包换。
B. 换货流程: 用户将产品、包装和原发票完整地拿到(或自购邮到)购买地点给商家检测——商家按原保规定期退换货,鉴定该产品是否有产品质量问题——商家为用户更换新品并开具新发票。

三、十二个月保修
A. 质保期限: 用户在awei直属专卖店或经awei授权的经销商所购买的产品,自购买之日起十二个月内,产品未受到任何人为或外力的损害而发生的产品质量问题,厂家保修。
B. 保修流程: 用户将产品、包装和原发票完整地拿到(或自购邮到)购买地点给商家检测——商家按原保规定期退换货,鉴定该产品是否有产品质量问题——商家将产品质保卡并加盖公章——商家将产品质保卡寄给厂家——厂家维修好即寄给商家——商家通知用户取货。

四、质保保规定
A. 质保产品: 包装盒、收纳袋、耳机夹、耳套等附属配件;不在三包期内的产品;非awei授权或非正规渠道所购买的产品;非awei正品;赠品;人为损害的产品;人为损坏的产品。
B. 质保界定: 三包范围(以质保卡为准)——非正品(非awei官方网店防伪码)——查产品损坏情况(有无明显人为造成的划痕、有无烧水、火、化学物质或重物砸伤的痕迹)——查产品质量(在产品使用过程中测试效果是否与产品描述相符)——查购买渠道(跟厂家查证)

香港雅乐电子有限公司 监制
深圳市雅乐电子有限公司 出品
广州·中国深圳龙华区天虹电器科技工业园
服务热线: 400-998-3899
售后邮箱: yale@awei.hk
售后服务: service@awei.hk

国外社址:
Twitter: <https://www.twitter.com/aweiofficial>
Facebook: <https://www.facebook.com/aweiproducts>
Instagram: https://www.instagram.com/awei_official

获取更多信息咨询:
www.awei.hk

官方微信验证码

awei产品保修卡(请认真填写完整)

产品型号	条形码
用户名	用户电话
用户住址	
商家名称	商家电话
商家地址	
购买日期	报修日期
损坏情况	维修时间
备注	

KA66
OUTDOOR PORTABLE
Wireless Speaker

User Manual

Dear awei User,

Thank you for choosing awei product. Your choice is crucial for us, which means awei has added-gained a new user. Hope that we will bring you good experience through our products and services. Also hope you will put forward good advice and suggestions by official customer hotline, Weibo and Wechat in the process of product experience, which can help awei constantly improve product and service.

If you encounter any problems in using products, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to awei. Thank you!

awei marketing team

Thank you for using awei products. Please read this manual carefully before using this product.

Accessories List

- 1x Wireless Speaker
- 1x USB-C Charging Cable
- 1x 3.5mm Audio Cable
- 1x User Manual

Overview Of Speaker

① Mode Button
② Next Track/ Volume Up
③ Built-in Microphone
④ Power On/Off
⑤ Indicate Light

⑥ Previous Track/ Volume Down
⑦ RGB Light Button
⑧ AUX Jack
⑨ USB Port
⑩ Type-C Charging Port

How To Use

Bluetooth connection

- When powered on for the first time, the speaker will automatically enter Bluetooth pairing mode and the blue light will flash. To pair, open your Bluetooth device and search for "awei KA66".
- Once connected, the blue light will remain on and you will hear a connection tone.
- To disconnect, simultaneously press and hold the "+" and "-" buttons. The blue light will flash and a disconnect tone will sound.

TWS Connection

- Turn on two identical speakers. Connect one to Bluetooth and then connect to TWS. After the connection, the indicator light of the main unit will be on and the secondary unit will flash. (Select one of the speakers and press and hold the "M" button to start pairing. After the connection with the secondary speaker is successful, you will hear a connection prompt tone.)
- Use your phone to connect to the primary speaker via Bluetooth and play music.
- Press and hold the "M" button to disconnect the pairing. The primary speaker will remain connected to your phone via Bluetooth.

Bluetooth Call

- The speaker has a built-in microphone and can be connected to the speaker via Bluetooth for making calls.
- Power Button: When a call comes in, short press to answer it, double press to reject it. During a call, short press to end it.

Mode Switch

The device defaults to Bluetooth mode upon power-up. When multiple audio sources are input, the playback order is as follows:
First: Bluetooth mode/Second: USB mode/Third: AUX mode
Short press the "M" button to switch audio sources in the order listed above.

How To Use

AUX mode

- Connect your device's AUX cable to the speaker's AUX jack. Once connected, the speaker will automatically switch to AUX mode.
- It will play music on the connected device.
- Short-press the power button to mute or unmute the speaker.

RGB lights

Turn on the speaker and the indicator light will flashes blue. Once connected to Bluetooth, you can choose from five lighting modes by pressing the "*" button on the top.

Mode 1: RGB lighting gently synchronizes with the music beat.
Mode 2: RGB lighting quickly synchronizes with the music beat.
Mode 3: Colorful lighting quickly synchronizes with the music beat.
Mode 4: Colorful lighting flows in sync with the music beat.
Mode 5: Rainbow lighting dynamically flows in sync with the music.
*The RGB lighting will flow in the direction of the volume adjustment.

Indicator light

Power off: The power indicator turns off.
Power on: The power indicator slowly flashes blue.
Bluetooth connected: The power indicator stays solid blue.
AUX IN mode: The power indicator slowly flashes blue.
USB mode: The power indicator slowly flashes blue.
Charging: The charging indicator stays solid red, and turns off when fully charged.

How To Use

Charge

For a better product experience, please fully charge the speaker before use. A Type-C charging cable is included (for charging only, not data transfer). Please charge with a 5V/2A adapter or a computer USB port. Using a non-standard 5V adapter may damage the product. Do not charge if the charging cable is damaged or the device is wet.

Power on/off

- Press and hold the power button for 2 seconds to turn on the speaker; you'll hear a power-on tone.
- Press and hold the power button for 2 seconds to turn off the speaker; you'll hear a power-off tone.
- The power-on/off tone is fixed, and the volume defaults to 30% of the speaker's maximum volume.
- When the battery is low, you'll hear a low-battery tone, and the speaker will automatically shut down after three beeps.

Power saving settings

The speaker will automatically shut down after 10 minutes in the following four conditions:

- In Bluetooth mode, the phone is not connected.
- In Bluetooth mode, the phone is connected, but there is no playback or operation for 10 minutes.
- In USB mode, the pause button is pressed, and there is no playback or operation for 10 minutes.
- In AUX mode, the pause button is pressed, and there is no playback or operation for 10 minutes.

Other

- In any mode, press and hold the ② button for more than 6 seconds to restore the device to factory settings, shut it down, and clear the Bluetooth pairing history.
- The default startup volume is 50% of the maximum volume. Playback time may vary depending on volume level and music style.

Specifications

1. Bluetooth version:	V5.3
2. Waterproof rating:	IPX7
3. Battery capacity:	3000 mAh/7.4V
4. Playtime:	7 hours (50% volume)
5. Charging time:	3 hours
6. Response frequency:	80-16kHz
7. Bluetooth effective range:	≥10M
8. Charging input:	DC 5V (Type-C)
9. Output power:	60W
10. Supported modes:	BT/USB/AUX/TWS/Hands-free calling/RGB lighting
11. Product dimensions:	96.2*96.2*237.7mm

Safety And Maintenance

Please read suggestions below in order to help prolong the product lifespan and clearly understand the warranty clauses.

- Keep the product dry, do not put it in humid circumstance to avoid short circuit.
- Do not expose it to the sunshine or high heat. High heating will shorten lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to take apart the product, especially non-professionals.
- Do not fall, vibrate strongly or strike with hard objects, to avoid damage to inner electronic circuit.
- Do not use high chemical products, detergent to clean the product.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not make it charge 10 hours continuously for the sake of lifespan.
- If the product can not work properly, please send it to awei authorized maintenance agency. Our staff will help to solve the problems for you.

Statement: In order to improve product performance we will upgrade products, the content may change without notice pls forgive! Thank you for your purchase.

Products after-sales service

1. 7 Days Refund Policy
A. Guarantee of Refund: Within 7 days since the date of purchase, the manufacturer promises to refund if the product bought from awei immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).
B. Refund Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should refund the money the user paid for the product.

2. 15 Days Replacement Policy
A. Guarantee of Replacement: Within 15 days since the date of purchase, the manufacturer promises to replace if the product bought from awei immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).
B. Replacement Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should replace the product and issue a new invoice to the user. Freight arrangements please check with the shop you contact.

3. Twelve Months Warranty Policy
A. Guarantee of Maintenance: Within twelve months since the date of purchase, the manufacturer promises to offer maintenance service if the product bought from awei immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).
B. Maintenance Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should replace the product and issue a new invoice to the user. Freight arrangements please check with the shop you contact.

4. Quality Assurance Identification Rules
A. Quality Assurance to NOT applicable to those items: accessories like packing box, pouch, ear clip and earplugs; product beyond warranty period; product got from unauthorized agents or informal channels; fake awei product; awei premium; artificial damaged product; external force damaged product.
B. Quality Assurance Identification Procedure: Check warranty period (by original invoice) — confirm original product (check security code on awei official website) — check product damage (clarify artificial damage and external force like water, fire, chemicals or weight crush damages) — check product quality (to confirm if the testing result is conform to description) — check buying channel (subject to manufacturer's verification).

香港雅乐电子有限公司 监制
深圳市雅乐电子有限公司 出品
广州·中国深圳龙华区天虹电器科技工业园
服务热线: 400-998-3899
售后邮箱: yale@awei.hk
售后服务: service@awei.hk

国外社址:
Twitter: <https://www.twitter.com/aweiofficial>
Facebook: <https://www.facebook.com/aweiproducts>
Instagram: https://www.instagram.com/awei_official

获取更多信息咨询:
www.awei.hk

For more information please visit:
www.awei.hk

官方微信验证码

awei Warranty Card (please fill this carefully)

Model No.	Barcode
User Name	Tel
Address	
Seller	Seller Tel
Seller Add	
Date of Purchase	Date for Maintenance
Damage Situation	Maintenance Time
Remark	